

FIELD ADJUSTMENT INSTRUCTIONS:

1. REMOVE THE BODY FROM THE TOP OF THE INDICATOR POST ASSEMBLY.
2. CUT THE REQUIRED LENGTH OF THE BOTTOM OF THE STANDPIPE FOR THE GROUND LINE TO MATCH UP WITH THE STANDPIPE GROUND LINE MARK.
3. CUT THE 1" SQ. EXTENSION AT A DISTANCE OF 9" ABOVE THE TOP OF THE STANDPIPE.
4. SET THE "OPEN" AND "SHUT" TARGETS FOR THE APPROPRIATE VALVE SIZE.
5. REATTACH THE BODY TO THE TOP OF THE INDICATOR POST ASSEMBLY.
6. LOCATION OF VALVE PER NFPA.

