

GENERAL NOTES:

1. TO BE USED WHERE EXCESSIVE STORMWATER VELOCITIES PROHIBIT VEGETATIVE LININGS AND WHEREVER STORMWATER OUTFALLS OVERLAP SEWER EASEMENTS.
2. STONE SIZE, TRENCH DEPTH, AND OVERALL WIDTH PER DESIGN.
3. FILTER FABRIC MUST BE INSTALLED BETWEEN RIPRAP AND SOIL FOUNDATION.
4. RIP RAP SHALL EMBEDDED IN THE CHANNEL CUT, NOT SIMPLY PLACED ON TOP OF EXISTING GROUND.

MAINTENANCE NOTES:

1. INSPECT RIP RAP CHANNEL WEEKLY AND AFTER RUNOFF-PRODUCING EVENTS TO SEE IF ANY EROSION AROUND OR BELOW THE RIP RAP HAS OCCURRED. IMMEDIATELY MAKE ALL NEEDED REPAIRS TO PREVENT FURTHER DAMAGE.
2. IF EROSION IS EVIDENT PAST END OF RIPRAP CHANNEL DUE TO RUNOFF DISCHARGING FROM CHANNEL, INCREASE DIMENSIONS OF RIP RAP PAD PROVIDED SPACE IS AVAILABLE WITH THE APPROVED LIMITS OF DISTURBANCE.
3. MAINTAIN ALL VEGETATION ADJACENT TO CHANNEL IN A HEALTHY, VIGOROUS CONDITION TO PROTECT CHANNEL FROM EROSION AND SCOUR DURING OUT-OF-BANK FLOW.

